



V Twin Powersports Inc
2900 Soffel Ave
Melrose Park, IL 60160
847.756.3800
info@vtwinpowersports.com

THROTTLE BODY CALIBRATION PROCEDURES

- 1. Once throttle body has been installed, make sure plug is connected**
- 2. Turn key & handlebar switch to 'ON' for 30 seconds, then shut 'OFF' for 30 seconds**
- 3. Repeat this procedure 4 times**
- 4. While doing this process, DO NOT touch the throttle**
- 5. This will reset your throttle body and let it learn the 'HOME' position**

UNDER NO CIRCUMSTANCES DO YOU ADJUST THE SET SCREW LOCATED ON THE THROTTLE BODY - THAT WILL NOT CHANGE YOUR IDLE POSITION.